

EXPANDABLE MULTIFUNCTION CONTROL PANEL

KYO 320



USER MANUAL



This system can be programmed using the respective (**KYO320**) Software Application 5.4.3 or higher.

Installation of the system must be carried out strictly in accordance with the instructions described in this manual, and in compliance with the local laws and bylaws in force.

The **KYO320** Control panels have been designed and manufactured to the highest standards of quality and performance.

The **KYO320** Control panels have no user-friendly components, therefore, should be serviced by authorized personnel only.

BENTEL SECURITY shall not assume the responsibility for damage arising from improper application or use.

The manufacturer recommends that the installed system should be completely tested at least once a month.

Hereby, Bentel Security, declares that **KYO320** Control panels comply with the essential requirements and other relevant provisions of Directive **1999/5/EC**.

Recycling information

BENTEL SECURITY recommends that customers dispose of their used equipments (panels, detectors, sirens, and other devices) in an environmentally sound manner. Potential methods include reuse of parts or whole products and recycling of products, components, and/or materials.

For specific information see: www.bentelsecurity.com/en/environment.htm

Waste Electrical and Electronic Equipment (WEEE) Directive



In the European Union, this label indicates that this product should NOT be disposed of with household waste. It should be deposited at an appropriate facility to enable recovery and recycling.

For specific information see: www.bentelsecurity.com/en/environment.htm

NOTE:

In addition to the present User Manual, the Installation and Programming from keypad Manual are also available for KYO320 control panel. It is possible to buy these manuals separately from the KYO320 control panel, or to download them from Bentel Security website: <http://www.bentelsecurity.com>.

The control keypads of KYO320 control panel are the CLASSIKA and PREMIUM LCD keypads. All previous Bentel LCD keypads (Alison-S, Alison-DVP, Mia-S, Mia-D) and the LED keypad Alison32LP continue to be supported by the KYO320 Control panel. For a correct functionality of PREMIUM and CLASSIKA LCD keypad, the KYO 320 control panel must have a firmware rev. 2.06 or higher.

BENTEL SECURITY srl. reserves the right to change the technical specifications of this product without prior notice.

TABLE of CONTENTS

OPERATING YOUR SYSTEM FROM A KEYPAD	5
Buzzer Volume	5
Contrast Adjustment	5
Brightness adjustment	6
Superkey functions	6
Audible and Visual signals on the Keypad	6
<i>LEDs</i>	6
<i>Display</i>	6
Basic Commands	8
<i>Arming Partitions</i>	
(<i><Code> ON</i>)	9
<i>Disarming Partitions</i>	
(<i><Code> OFF</i>)	9
<i>Arming in A, B, C or D Mode</i>	
(<i><Code> A, B, C or D</i>)	9
<i>Quick Arming for PREMIUM LCD and CLASSIKA</i>	
<i>LCD keypad</i>	9
<i>About Partition Arming</i>	9
<i>Quick View Trouble Mode (ENTER)</i>	10
<i>Partition status enquiry</i>	10
Accessing the User menu (<Code>ENTER)	10
<i>Reset Alarms and Tamper</i>	11
<i>Stop Alarms</i>	11
<i>Arm/Disarm</i>	11
<i>Zone status</i>	11
<i>Event Log</i>	12
<i>Enable/Disable Auto-arm</i>	13
<i>Teleservice request</i>	13
<i>Enable/Disable Teleservice</i>	13
<i>Enable/Disable Answering device</i>	13
<i>Activating Outputs (Turning ON/OFF Appliances)</i>	13
<i>Clear call queue</i>	13
<i>Overtime request</i>	14
<i>Change Time and Date</i>	14
<i>Change Telephone numbers</i>	14
<i>Reset PC programming</i>	14
<i>Programming PIN codes</i>	14
<i>Memo</i>	15
<i>Disable buzzer</i>	16
<i>Test Siren</i>	16
<i>Test Keypad</i>	16
<i>Continuous recording</i>	16
<i>Enable/Disable Timers</i>	16
<i>Enable/Disable Key</i>	17

USING DIGITAL KEYS AND CARDS	19
Readers	19
Digital Keys/Cards	19
The Reader LEDs	20
<i>No Key/Card at Reader</i>	20
<i>Key/Card at Reader</i>	20
Multiple Systems	20
Digital Key/Card operations	21
<i>Disarm (Turning OFF your system)</i>	21
<i>Arm — Global Mode (Turning ON your system)</i>	21
<i>Arm — A Mode</i>	21
<i>Arm — B Mode</i>	21
<i>Stop Alarms (for ECLIPSE Readers ONLY)</i>	22
<i>Arm/Disarm Patrol</i>	22
The Wireless Key	22
<i>Global Mode</i>	22
<i>Stay Mode</i>	22
<i>Disarm</i>	22
<i>Other functions</i>	22
<i>Low Battery</i>	22

OPERATING THE SYSTEM FROM A TELEPHONE	23
Remote Access via 'Dialler' mode	23
Remote Access via 'Answer' mode	23
<i>Teleservice Enabled</i>	23
<i>Teleservice Disabled</i>	23
Typing-in your User Code PIN	23
Entering Commands	23
Default PINs (Factory default)	25

OPERATING YOUR SYSTEM FROM A KEYPAD


Read this section thoroughly so si regola il volume a zero, il buzzer emetterà comunque dei suoni ad un volume minimo DURANTE LA FASE DI REGOLAZIONE.

ughly to get an overall view of how to operate your system from a Keypad. KYO 320 can manage 32 **PREMIUM LCD** and/or **CLASSIKA LCD** Keypads (Fig.1) and 16 Alison/32LP.

- **PREMIUM LCD** has a larger display with 2 lines and 16 columns and has a built-in Proximity Reader. Premium LCD keypad provides 3 fast keys for instant activation of Burglar, Fire and Emergency Alarms (to be programmed by your Installer);
- **CLASSIKA LCD** has a larger display with 2 lines and 16 columns but on the contrary of PREMIUM keypad has NOT a built-in Proximity Reader. CLASSIKA LCD keypad provides 3 fast keys for instant activation of Burglar, Fire and Emergency Alarms (to be programmed by your Installer)

Figure 1 shows the main components of the **PREMIUM LCD** and **CLASSIKA** Keypads:

- 1 Function LEDs
- 2 Display
- 3 Keys
- 4 Down flip
- 5 Information chart
- 6 Sensitive field
- 7 Fast Keys



Buzzer Volume

To adjust the volume of the internal buzzer, follow the procedure described below:

- 1) Press and keep pressed the **ESC** key; the internal buzzer will start sounding a series of beeps in such manner that the operator could hear the sound level in real time.
- 2a) To increase the volume, press key **A** for a number of times and/or keep it pressed until the desired level is obtained.
- 2b) To lower the volume, press più volte and/or keep pressed key **B** until the desired level is obtained.
- 3) To confirm the chosen level, press the **ENTER** key (or wait a few seconds for the keypad to return to the inactive state).

NOTE – The buzzer will still emit a series of sound alerts at extremely low volume, even if it has been set to zero.

Contrast Adjustment

To adjust the contrast of the LCD display, press and hold:

- **C** to increase contrast
- **D** to decrease contrast

To confirm the selected levels, press ENTER (or simply wait a few seconds to enable the keypad back into the stand by status) (see the PREMIUM keypad manual for further information).




Figure 1 - a) PREMIUM LCD Keypad, b) CLASSIKA LCD Keypad.

Brightness adjustment

The brightness can set in a normal way or in the stand by status (the keypad enables the stand by status brightness after 10 seconds of inactivity).


To adjust the brightness of the LCD display, press and hold:

- **A** to increase brightness
- **B** to decrease brightness

Press **OFF** to set the stand by brightness.

ON and **OFF** alternate, respectively, the settings for the normal and the stand by status level.

To confirm the selected levels, press ENTER (or simply wait a few seconds to enable the keypad back into the stand by status).

 If the brightness in the "stand-by status" is set to a minimum, the keypad LEDs go out except in an alarm or fault condition (see Manual of keypads).

Superkey functions

If your Installer has set up the 'Superkeys', you will be able to perform some "Quick" operations from the keypad without using codes. The table shows how to activate the programmed functions.

PREMIUM LCD CLASSIKA LCD	Activation method
1	Press and hold the key for approximately 3 seconds
2	Press and hold the key for approximately 3 seconds
3	Press and hold the key for approximately 3 seconds

The 'Superkeys' can be set up to activate:

- Electrical appliances (e.g. Heating system, Lights, etc.)


- the Digital communicator
- the Dialler

The 'Superkey' actions are instant and will be confirmed by a feed back signal (beep).

The Superkeys can be set up to work differently on different Keypads.

Audible and Visual signals on the Keypad

Table 1 shows the meaning of the indicator LEDs on the PREMIUM LCD and CLASSIKA LCD Keypads.

 Some of the display screens differ, depending on whether the keypad has been set with the option "Compatibility with EN50131" or not.

■ LEDs

Refer to Table 1 for the description of the four LEDs on the Keypad.

■ Display

During standby status, the first line will show the Time and Date, as follows.



1 2 3 4 5 6 7 8 

If the keypad has been set in EN50131 mode, the standby display screen will be similar to the one show below:








 The text "Enter PIN" can be programmed by the installer.

TABLE 1 - KEYPAD LEDs

Symbol	Meaning
	<p>Off: all the keypad Partitions are Disarmed</p> <p>On: at least one of the keypad Partitions is Armed</p> <p>Slow blinking: STOP ALARMS function is Active</p> <p>Fast blinking: STOP ALARMS function is Active and AT LEAST ONE of the keypad Partition is Armed.</p> <p>NOTE - With EN50131 keypad, the indicator light is always off: to display the various functions listed above, you will have to enter the "View zone status" mode.</p>
	<p>Off: Standby status -NO alarms-</p> <p>On: Zone Alarms in memory</p> <p>Slow blinking: Tamper on at least one zone or on thr Control panel</p> <p>Fast blinking: Alarm and Tamper on at least one zone, or Tamper on the Control panel</p>
	<p>Off: No trouble conditions detected</p> <p>On: At least one Trouble condition detected</p> <p>Slow blinking: At least one zone in Test status</p> <p>Fast blinking: At least one zone in Test status and one in Trouble status</p>
	<p>Off: No voice messages in memory</p> <p>On: At least one voice message in memory</p>
<p>Note: The zone Alarm and Tamper events, signalled on the LEDs, refer to zones which belong to the keypad Partitions.</p>	

If the Control panel has stored a zone Alarm or Tamper event (▲ LED on or blinking, respectively), the first line will show the description of the zone concerned, as follows.



1 2 3 4 5 6 7 8

If the Control panel has stored several zone Alarms and/or Tamper events in the memory, the first line will show the zones concerned (one-by-one at 3 second intervals). The second line will provide information on the status of the Partitions. The left-hand side of the display will provide information on the status of the Keypad Partitions, as shown in Table 3.

KYO 320 manages 32 Partitions. However, only 8 Partitions can be viewed on PREMIUM LCD and CLASSIKA LCD Keypads. Therefore, the numbers below the display will correspond only when the first 8 Partitions are selected (refer to Quick View Partition mode).

Trouble conditions will be signalled on the right-hand side of the second line. The trouble conditions are represented by the Icons directly below the display. Memory of Trouble conditions will be indicated by an “x” above the respective Icon (refer to Table 4 for details). If the Teleservice or Answering Machine facility is Enabled, an asterisk (*) will be shown above the respective Icon (refer to Table 5 for details).

If the Telephone line is busy or down, a will appear above the Icon (refer to Table 4 for details).

■ Buzzer

The Keypad sounder will emit a beep each time you press a key. It will also signal:

- the Exit time (slow beeps);
- the Entry time (fast beeps);
- the Auto-arm timeout (four-beep sequence);
- if the respective option is enabled, Partition Alarm or Tamper event in memory (two-beep sequence);
- data input errors or invalid operations (buzz).

TABLE 2 - ARMING/DISARMING PARTITIONS (LCD KEYPADS)

Initial	Mode	Result
	Away	The system will turn ON the perimeter and interior zones of the respective Partition
	Stay	The system will turn ON the perimeter zones of the respective Partition and will leave the interior zones OFF.
	Stay 0 Delay	The system will turn ON the perimeter zones of the respective Partition and will leave the interior zones OFF, and will remove the ENTRY TIME from zones which have one.
	Disarm	The system will turn OFF the perimeter and interior zones of the respective Partition.
....	Disabled	The respective Partition is not a Keypad Partition, therefore, cannot be controlled from the keypad.

Note: If the Partition has one or more Alarms in memory the letter will blink.

TABLE 3 - TROUBLE SIGNALS (LCD KEYPADS)

Icon	Signalled by	Meaning
		ON - Control panel Tamper (Control panel open or dislodged) Blinking - Control panel Tamper has cleared but at least one Open Panel event in memory
		ON - System Tamper Blinking - System Tamper has cleared but there is at least one System Tamper event in memory
		ON - Tamper on at least one peripheral device (Keypad, Reader, Expander or Receiver) Blinking - Peripheral Tamper has cleared but there is at least one Peripheral Tamper event in memory
		ON - A False Key/Card is present at a Reader Blinking - At least one False Key/Card event in memory
		ON - A peripheral device (Keypad, Reader, Wireless or Expander) has been disconnected Blinking - At least one Peripheral Trouble event in memory

NOTE: To clear the and Trouble signals, select the **Reset Alarm** option from the User Menu.

TABLE 4 - TELEPHONE SIGNALS (LCD KEYPADS)

Icon	Signalled by	Meaning
	*	OFF - Teleservice Disabled ON - Teleservice Enabled
	*	OFF - Answerphone facility Disabled ON - Answerphone Facility Disabled
		OFF - Line Free ON - Line Busy Blinking - Line Down

Basic Commands

You can control eight basic commands from standby status by typing-in your code and pressing the respective keys (refer to the following Table). Access to ALL commands — except 'View Trouble' — require entry a valid User Code PIN.

Keypad set normally	
Enter	COMMAND
<Code> ON	Arm
<Code> OFF	Disarm
<Code> A	A Mode Arm
<Code> B	B Mode Arm
<Code> C	C Mode Arm
<Code> D	D Mode Arm
<Code> ENTER	Access User Menu
ONLY ENTER	"View trouble" mode
ONLY ESC	List "By-passed zones"/"By-passed zone"

Keypad set as EN50131	
Key sequence (from standby status)	COMMAND
<Code> ON	Arm
<Code> OFF	Disarm

<Code> A	A Mode Arm
<Code> B	B Mode Arm
<Code> C	C Mode Arm
<Code> D	D Mode Arm
<Code> ENTER	View Area status if there are no malfunctions, otherwise View malfunctions. From the View area status or malfunctions screen, press ENTER again to access the User menu.

☞ 'View Trouble' mode is available on LCD Keypads at all times, and can be accessed without entering a Code.

☞ Commands will affect **only** the Partitions common to both the User code and Keypad concerned (common Partitions).

Invalid commands will be signalled by a buzz and the following message:

```
17:05 26/08/2005
Invalid code!
```

invalid commands may be due to the User code or the Keypad (e.g. the User code is Disabled on the Keypad Partitions).

TABLE 5 - "VIEW TROUBLE" MODE

Message	Description
Tr oub. pow. syst .	The Control panel battery or at least one Power Station is not functioning properly
Low bat t er y	The Control panel battery or at least one Power Station battery is low
AC Mai ns f ai l ur e	The Mains power to the Control panel or to at least one Power station has failed
Bat t . di sc. pw. s.	At least one Power Station has disconnected its Battery
Faul t chr g. pw. s.	At least one Power Station has Battery-charger trouble
Swt ch. di sc. pw. s.	At least one Power Station has disconnected its Battery-charger
Out short pw. s.	At least one Power Station has one Output in short-circuit
Tel. line troub.	Line down
Fuse B1	Shortcuts/blown fuse on terminals +N1 and +A1 (1.85A-250V)
Fuse B2	Shortcuts/blown fuse on terminals +N2 and +A2 (1.85A-250V) KYO320 only
Fuse B3	Shortcuts/blown fuse on terminals +N3 and +A3 (1.85A-250V) KYO320 only
Fuse B4	Shortcuts/blown fuse on terminals +B4 (1.85A-250V) KYO320 only
Fuse B5	Shortcuts/blown fuse on terminals +B5 (1.85A-250V) KYO320 only
Fuse +F	Shortcuts/blown fuse on the power line +F (1.85A-250V)
Fuse BPI 1	Shortcuts/blown fuse on BPI line1 (1.85A-250V)
Fuse BPI 2	Shortcuts/blown fuse on BPI line2 (1.85A-250V)
Fuse KEYBUS	Shortcuts/blown fuse on the Key Bus (500 mA-250V)
St op al. j ump. i n	STOP ALARM jumper is connected
Low bat t er y WLS	Low Battery on one or more Wireless devices
Var n. l i t h i u m bat t	The RAM battery must be replaced
Cal l I nst al l er	Service is due — Call your Installer
Cal l Cent r. St at .	Central Station intervention is due — Call your Central Station
Dayl i ght Savi ng	The Control panel Clock has been turned forward/back
WLS Devi ce l ost	Connection problems with a Wireless device (Missing or Trouble present)
Cl ock St opped	The Control panel Clock has stopped
Vox board l ost	Connection problems with the Vox Board (Missing or Trouble)
St art pr ogr am	Programming session via PC (on-site or via Modem) started during Disarmed status
I nact i vi t y	The zone "Inactivity Time" has expired
Di scl o sed PI N	A PIN (DUPLICATED at random) has been DISCLOSED to another User

If you do not press a key within 30 seconds, the keypad will revert automatically to standby status.

The User can enter the following commands at the Keypad.

■ Arming Partitions (<Code> ON)

This command will Arm all the common Partitions of the User code and the Keypad concerned.

DO NOT assign Duress Codes to Arming commands.

■ Disarming Partitions (<Code> OFF)

This command will Disarm all the common Partitions of the User code and the Keypad concerned.

Disarm under Duress

This command requires entry of a **Duress Code**. The Control panel will Disarm the Partitions and will send the programmed Alarm calls but will not signal the outgoing calls on the Keypad (usually signalled by a over the icon).

Disarm by Patrol Code

If a Patrol Code is used to Disarm the Partitions, the Control panel will rearm the Partitions automatically when the programmed Patrol Time expires.

■ Arming in A, B, C or D Mode (<Code> A, B, C or D)

DO NOT assign Duress Codes to A, B, C or D Mode Arming commands.

Each user code can be set up to manage four different Arming mode configurations: A, B, C and D. These configurations determine the Partitions that will Arm, and those that will Disarm when an A, B, C or D Mode command is entered at a Keypad (the final configuration depends on the User code and Keypad Partitions).

Keypads can operate ONLY on the Partitions they are assigned to.

■ Quick Arming for PREMIUM LCD and CLASSIKA LCD keypad

1. Press **ON**: the Keypad will sound a beep.
2. Press and hold the **ON** key for approximately 3 seconds, the Keypad will sound a second beep, and the display will show the following message:

```
Quick Arming _____
Type: A, B, C, D _____
```

3. Press **A, B, C** or **D** within 4 seconds (to Arm in A, B, C or D mode, as required). If you do not press a key within 4 seconds the Control panel will Arm the Partitions automatically in Away mode.

Quick Arm operations will affect the Keypad Partitions and the Partitions assigned to the Quick Arm method.

Your Installer will tell you which Keypads can be used, and which Partitions are involved.

You can Arm/Disarm the Partitions separately using a 6-digit User Code PIN, as follows: — type in a 6-digit User Code PIN followed by the 2-digit ID number of the Partition concerned, then press ON, OFF, A, B, C or D, as required. The partition concerned will Arm/Disarm in accordance with programming.

Example: If the 6-digit User code PIN is **135790**, and you want to Arm Partition **13** in Away Mode, type-in **13579013** then press ON. If you want to Disarm Partition 13, using the same PIN, type-in **13579013** then press **OFF**. If you enter 13579013 then press **A, B, C** or **D**, Partition 13 will Arm in accordance with the respective configuration.

■ About Partition Arming

If you Arm a Partition with an Exit Time, the Keypad will emit slow beeps to signal the elapsing Exit Time.

If you arm several Partitions with different Exit Times, the Keypad will emit slow beeps until all the Partition Exit Times expire. However, each Partition will Arm when its own Exit Time ends.

When you enter a valid Arming command at a Keypad, the Control panel will check for:

- a) Zones in Alarm
- b) Inactive Zones
- c) Bypassed Zones
- d) WLS delinquency zone

The Partitions will Arm instantly if none of these conditions is present. If the system detects zones in Alarm, Inactive and/or Bypassed and/or WLS delinquency status, the respective message will be shown on the display.

```
Open Zones!
Arm? 
```

```
Open Zones!
View by P. Zones? 
```

The second message only appears if the “Disable activation with alarmed areas” option has been selected.

If this condition is present:

- press **B** then, scroll for the zones concerned. Ensure that all the zone doors and windows are closed securely, and that there is no motion in the vicinity of motion detectors;
- press **ESC** to abort the command, then retry.

All zone Alarms must be cleared before Arming the Partitions otherwise Arming will generate an Alarm.

```
Inactivity!
Arm? 
```

If this condition is present:

- press **B** to view the Inactive zones.
- press **ESC** to abort the command, then retry.

```

By-passed Zones!
-----Arm?----- ↓
  
```

If this condition is present:

- press **B** to view the Bypassed zones.
- Ensure that no zones have been bypassed (turned OFF) unintentionally. If necessary, use the ON key to UnBypass (turn ON) Bypassed zones. Press **ENTER** to Arm the Partitions.

☞ *All zones must be unbypassed before Arming the Partitions otherwise security will be greatly reduced.*

In the following example, zone 5 has been BYPASSED.

```

Zone      005
STBY BYPASSED
  
```

☞ *Use **A** or **B** to scroll the zones in Alarm, Inactive or Bypassed status.*

■ Quick View Trouble Mode (ENTER)

Your system will continuously check for Trouble conditions. If a Trouble condition occurs, the Amber ▲ LED on the Keypad will turn ON.

To check current Troubles (from standby):

Press the **ENTER** key on the Keypad.

(If the Compatibility with EN50131 option has been set, it will be necessary to set the user code followed by the ENTER button, then press the ENTER button a second time).

If several Trouble conditions are present:

Use **A** or **B** to scroll the list (Table 5 shows the various Trouble conditions).

```

Current trouble:
Loss of clock
  
```

If you access the **View Trouble** Mode and no Trouble conditions are present, the display will show the following message:

```

Current trouble:
none!
  
```

Press the **ENTER** key to exit.

■ Partition status enquiry

Press the **ON** key to view the status of the Keypad Partitions:

```

DD-I-PZ--DDDDII
---IIIFZZ--DI---
  
```

The first line of the display will show (from right to left) the status of Partitions no. 1 through no. 16, the second row of the display will show (from left to right) the status of Partitions no. 17 through no. 32. The hyphen (-) indicates that the Partition is not a Keypad Partition.

The Partition status will be shown for approximately 6 seconds.

☞ *Partition status enquiry is possible on Enabled Keypads only. If Partition Alarm or Tamper is present the respective character will blink.*

☞ *“View Trouble” mode provides information regarding zones which generate “Low Battery WLS” and “WLS Device lost” events. For the event details (i.e. information regarding the zone concerned), press **D**.*

Accessing the User menu (<CodeENTER)

(for PREMIUM LCD and CLASSIKA LCd Keypads)

Enter a valid User Code then press the ENTER key to access the User menu. The User menu will allow Users to access ONLY the commands they are enabled for.

☞ *You can access the User menu when the Control panel is Armed or Disarmed.*

☞ *(If the Compatibility with EN50131 option has been set, it will first be necessary to enter the code for View control unit status mode, then press ENTER to access the User menu).*


Using **A** and **B**, scroll for the required option then press the **ENTER** key.

Press **ESC** as many times as required to step back and exit the menu.

☞ *Several Users can access the menu at the same time from different keypads.*

The User menu provides the following options:


- Reset Alarms**
- Stop Alarms**
- Arm/Disarm** — This line will blink
- Overtime request** — This line will be solid
- Overtime request**
- Enable/Disable auto-arm**
- Enable/Disable Teleservice**
- Enable/Disable Answering device**
- Disable buzzer**
- Change Telephone number**
- Program PINs**
- Change Time and Date**
- Reset PC Programming**
- Test Keypad**
- Test Siren**
- Activate Outputs**
- Zone status**
- Continuous recording**
- Memo**
- Event logger**
- Clear call queue**
- Enable/Disable Timers**
- Enable/Disable Key**

 *Your Installer has programmed your Control panel with your requirements in mind. Therefore, some of the options may not be available*

This system can manage 195 User Codes. Only the first User Code (**0001**) is **Active** and can operate the system.

Your Installer will enable and program as many User Codes as necessary. The programmed Access Level defines the User Code Partitions (the Partitions the User Code can control) and the User Code options (the options the User Code can access). **The menu will show the options the entered User Code is enabled for.**

The following paragraphs describe all the Options on the User menu.

 *The commands will affect ONLY the common Partitions of the User Code and Keypad concerned.*

■ Reset Alarms and Tamper

This command will allow you to restore all Alarm signalling devices to Standby, and delete the zone and Partition Alarm memories.

Once the command has been executed, the display will show the following message:





Figure 2 *Partition status.*




If Alarm signalling persists after a **Reset Alarms** command, select the **Stop Alarms** option. The causes of persistent Alarms must be cleared immediately.

■ Stop Alarms

This command will allow you to stop and freeze all the Alarm signalling devices. This status can be undone by pressing any key. During this phase the Control panel will be unable to trigger Alarms, and the display will show the following message:



The first line flashes while the second remains fixed.

The  indicators on Keypads, assigned to any of the Partitions of the Keypad concerned, will blink.

■ Arm/Disarm

This command will allow you to Arm or Disarm the Partitions one by one, as follows:

1. Use **A** and **B** to scroll the Partitions common to both the Keypad and User Code concerned (the current status will be indicated on the second line).



meanings of the **X**'s that may appear on the second line can be found in Figure 2.

2. Press the **ENTER** key to select the required Partition. The display will show the Arming options, as follows:



3. Press the relevant key to select the required mode:

- 1 - Away
- 2 - Stay
- 3 - Stay with 0 delay
- 4 - Disarm

4. Press the **ESC** key to step back to the User menu.

■ Zone status

This command will allow you to turn ON/OFF (UnBypass/Bypass) the zones of the User Code Partitions. The display will show the **BYPASSED** or **UNBYPASSED** status, and the current condition of the zone, as follows:

- **ALARM** (Alarm conditions present)
- **TAMPER** (Tamper conditions present e.g. Wires cut)
- **SHORT** (Tamper conditions present e.g. Short-circuit)
- **STBY** (zone in standby status)

NOTE: You must call your Installer if any zones signal Tamper or Short-circuit.

1. Use **A** and **B** to scroll the zones of the Partitions common to the Keypad and User Code concerned.

```
zone n. 002
sitting room
```

2. Press the **ENTER** key to select the required zone. The display will show the zone status, as follows

```
Sitting room
STBY UNBYPASSED
```

3. Using the **ON** and **OFF** keys UNBYPASS (turn ON) or BYPASS (Turn OFF) the zone, as required.

4. Use **A** or **B** to scroll the zones and continue, or press the **ESC** key twice to step back to the User menu.

*Attempts to Arm (turn ON) the Partitions when zones are Bypassed or in Alarm status will activate the **Zones status** list automatically. Only the zones that are about to be Armed will be included in the list.*

*You can Bypass a Zone using a 6-digit User Code PIN, as follows: — type in a valid 6-digit User Code PIN followed by the 3-digit ID number of the Zone concerned then press **ESC**. For example, if the PIN is 135790 and you want to Bypass Zone 23, type in 135790 023 then press **ESC**.*

■ Event Log

This command will allow you to view and print the events in the Event Log. The Control panel Event log can store up to 10,000 events. The events will be stored in chronological order—starting from the most recent.

Each event shows the following details:

- **Ev.** (Event number)
- **TYPE** (e.g. Zone Alarm, Invalid Code, etc.)
- **IDENT** (e.g. Zone number, Partition, etc.)
- **AGENT** (e.g. Keypad, Reader, etc.)
- **ID.AGEN** (e.g. User code, Card/Key, etc.)
- **TIME** (Time and Date of the event)

The display will show the following message:

```
EVENT LOGGER
From Last ...
```

To view all Events

Press the **ENTER** key to view all the Events in the Log—starting from the most recent (from last . . .).

Use **A** and **B** to scroll the Events.

Press **D** to view the Event details (see above).

To view Events from a specific Date

```
EVENT LOGGER
starting from..
```

Using **A** or **B** scroll for the following message:

Press the **ENTER** key, the display will show the Date prompt.

```
Starting from..
10/09/2006
```

Enter **all** the digits of the required Date (DD/MM/YYYY), then press the **ENTER** key.

Use **A** and **B** to scroll the Events.

Press **D** to view the Event details (see above).

```
Ev.00015 TYPE
Valid code
```

*The display will show the relevant details for each Event. For example, Tamper Events show the **TYPE** and **TIME** only.*

To print Events from a specific Date

Using **A** or **B** scroll for the following message:

```
EVENT LOGGER
print from..
```

Press the **ENTER** key, the display will show the Date prompt.

```
Starting from...
10/09/2005
```

Enter **all** the digits of the required Date (DD/MM/YYYY), then press the **ENTER** key.

The Keypad will exit the **USER MENU**, and the Printer will print the Events starting from the entered date to the most recent.

This facility is provided by the optional K3-PRT2 Printer Interface (ask your Installer for details).

The Event Log


The Event log is set up as follows:

- the Event number (**Ev.**) is shown on the left side of the first line;
- the Event details (**TYPE**, **IDENT.**, **USER**, **USER ID**, **TIME**) are shown on the second line.

```
Ev.00015 TYPE
Valid code
```

Using the Event Log:

- Use **A** and **B** to scroll the Events.
- Press **D** to view the Event details (see above).
- Press the **e** to step back to the **Event Log** menu.

 The display will show the relevant details for each Event. For example, Tamper Events show the TYPE and TIME only.

■ Enable/Disable Auto-arm

Your Installer may have set up Partitions to turn ON/OFF at preset times. This command will allow you to turn the **Scheduler** ON/OFF, and Enable/Disable automatic ON/OFF control.

Use **A** and **B** to scroll the Partitions, and the **ON** and **OFF** keys to Enable/Disable the Scheduler.

```
Partition 001
Scheduler OFF
```

Press the **ESC** key to step back to the User menu.

■ Teleservice request

If your Installer has set up this facility, this command will allow you to request on-line assistance (maintenance that does not require components or wiring). Teleservice requests will be confirmed by the following message:

```
USER MENU
done!
```

The Teleservice request will stop any ongoing Telephone calls (Teleservice requests from the User have priority over other call types), and will send the Teleservice call (or calls) to the Installer telephone number (or numbers).

■ Enable/Disable Teleservice

This command will allow you to Enable/Disable the Control panel to receive Teleservice calls. The command will be confirmed by the following message:

```
En./Dis. Service
Service OFF
```



ON to enable procedures with the installer code
OFF to disable procedures with the installer code

Press the **ENTER** button to confirm and return to the User menu.

If the user enables the Maintenance mode (Maintenance ON) and the control unit is connected to the telephone line, the installer will be able to perform the following procedures remotely, as well as on site:

- **View the Control panel status** — Partition status; Alarm memory, Bypassed zones, Zone status, Event logger, Peripheral device status, etc.
- **Change the Control panel status** — Change Partition status, Clear the Alarm memory and Bypass zones (active User Code required).
- **Change the Control panel parameters** — if all the partitions are disarmed and the Partition Patrol Times are not active.

The Teleservice facility allows the Installer to check and work on the Control panel from a remote computer, and carry out maintenance work that does not require new wiring or components.

 An * will be shown on the display directly above the  when the Teleservice facility is enabled.

■ Enable/Disable Answering device

This command will allow you to turn ON/OFF the Answering device. If the Answering device is ON, the Control panel will answer incoming calls with a Voice message. This facility is provided by the **K3-VOX2** Voice board (accessory item).



The Answering device can function even if the **K3-VOX2** Voice board is absent, but in this case there aren't voice messages. When you select this command, the display will show the following message:

```
En./Dis. Ans. Dev.
Answer dev. OFF
```

Press **ON** to Enable the Answering device facility.

Press **OFF** to **Disable** the Answering device facility.

Press the **ENTER** key to confirm and step back to the User menu.

 If the Answering device facility is enabled, an* will be shown on the display directly above the .

■ Activating Outputs (Turning ON/OFF Appliances)

If your Installer has set up your system to control appliances (sprinklers, lights, etc.), this command will allow you to turn the appliances ON/OFF manually.

To turn ON/OFF Outputs (appliances):

1. Use **A** and **B** to scroll the list.

```
Output n. 001
Output 001
```

2. Press the **ENTER** key to select the required Output (appliance). The display will show the current status.

```
Output 001
INACTIVE
```

3. Press **ON** or **OFF**, as required.

Use **A** and **B** to continue scrolling the list.

4. Press the **ESC** key twice to confirm and step back to the User menu.

■ Clear call queue

If your Installer has programmed your Control panel to send Alarm calls, it will call the programmed telephone numbers each time an Alarm occurs. In the event of a False Alarm, this command will allow you to interrupt the ongoing call, and clear the call queue.

If you select this command the display will show the following message:

```
CLEAR CALL QUEUE
Confirm?
```

To confirm the Command

Press the **ENTER** key.

The display will show the following message for several seconds before stepping back to the User menu:

```
CLEAR CALL QUEUE
done!
```

To Abort the Command


Press the **ESC** key to step back to the User menu.

■ Overtime request

If the Auto-arm option is enabled, and the system is programmed to Arm automatically at a preset time, the Overtime request will allow you to delay the Auto-arming event.

Acceptance of the Overtime Request will be confirmed by an audible feed back signal and the following message:


```
OVERTIME REQUEST
done!
```

 *If any of the Partitions concerned is unable to implement the Overtime request, the Keypad will emit an audible error signal.*

The Installer will set up the Auto-arm and Overtime Request events with your installation in mind, and will provide you with all the necessary information (regarding the partitions involved, and the number of Overtime requests you can make before an Auto-arm event).

■ Change Time and Date


This command will allow you to set the current Date and Time.

 *You cannot change the Time and Date when Partitions are Armed.*

1. Using **A** or **B** select NEW TIME - DATE, then press **ENTER**.

```
NEW TIME - DATE
11:48 02/08/2002
```

2. Enter the New Time and Date, then press **ENTER** to confirm and go to the next step (Date format), or **ESC** to quit and step back to the USER MENU.

 *The New Time and Date field will not allow you to change the digits individually, therefore, you must enter the entire Time and Date. If you press **ENTER** before completion, the setting will be deleted.*

```
Date format
hh:mm dd/mm/yyyy
```

3. Using **A** or **B** select Date format:

hh:mm dd/mm/yyyy

hh:mm mm/gg/yyyy

hh:mm yyyy/mm/dd

then press **ESC** to confirm and go back to step 2.

■ Change Telephone numbers

This command will allow you to change the first eight Telephone numbers in the Phonebook.

To program or change the Telephone numbers:

1. Using **A** and **B** scroll the 8 Telephone numbers.

```
Change tel. num.
Telephone n. 001
```

2. Press **ENTER** to select the number to be programmed or changed.

The display will show the current Telephone number, or an empty programming field (the first digit will blink to indicate that it is ready for programming).

```
Telephone n. 002
0735556666
```

3. Using keys **0** through **9**, enter the telephone number.

— **OFF** corresponds to the pound sign (#);

— **ON** corresponds to pauses (*);

— **C** and **D** will allow you to move the cursor along the line and overwrite wrong digits.

To delete the entire Telephone number, press and hold **1** until the keypad emits a beep.

4. Press the **ESC** key to go back to step 1.

■ Reset PC programming

When the system is programmed from a computer (on-site or via Modem) or a Keypad, the **Control panel** will trigger the **Programming Start** event.

The Control panel classifies this event as a Trouble condition, therefore, it will be signalled on the **▲ LED**.

To view this Trouble condition, you must access *View Trouble* mode, the display will show the following message:

```
Current trouble:
Start program.
```

To clear this Trouble condition—select the **Reset PC Prog.** option from the User menu and press the **ENTER** key, the display will show the following message for several seconds and the **▲ LED** will turn OFF (unless there are other Trouble conditions present).

```
USER MENU
done!
```

■ Programming PIN codes

If your Installer has set up the User Code hierarchy (*Master and Slave Codes*).

This command will allow **Master Codes** to select/deselect the **Active** status of their *Slave Codes* (Enable/Disable *Slave Codes*), and change their *Slave Code PINs*.

 *This command is available to **Master Codes only**.*

Active Slave Codes can access the system and control their enabled Partitions and functions.

To allow/deny system access to a *Slave Code*:

1. Use **A** and **B** to scroll the *Slave Codes* list (accessed by the *Master Code*).

```
Code n. 001
Code 001
```

2. Press the **ENTER** key to select the required Code.

```
Code 001
Active
```

3. Press the **ON** key to select **Active** status, or **OFF** to deselect **Active** status, as required.

You can be both a Master and a Slave (i.e. Slave of one Code, and Master of another). A Master Code cannot deselect the Active status of a Slave Code that is Master of another Slave Code.

To change the PIN of a *Slave Code*:

1. Use **A** and **B** to scroll the list of *Slave Codes* (accessed by the *Master Code*).

```
Code n. 001
Code 001
```

2. Press the **ENTER** key to select the required Code.

```
Code 001
Active
```

3. Press the **ENTER** key again, the display will show the following message:

```
Enter new PIN
PIN *****
```

4. Enter the new **PIN** (4 to 6 digits) — * will replace X as you enter the new digits.

5. Press the **ENTER** key, the display will show the following message:

```
Repeat new PIN
PIN *****
```

In the example above, two digits have been entered.

6. Enter the new **PIN** again, the press the **ENTER** key to confirm and go back to step 1.

If necessary, press the **ESC**: key to abandon the procedure and go back to step 1.

You cannot assign the default PIN of one code to another Code (refer to Table 9).

If you attempt to assign the default PIN of one Code to another Code, the display will show the following message:

```
Repeat new PIN
Invalid code!
```

You cannot assign a PIN that already exists on the system.

If you attempt to assign a PIN that has already been assigned to another Code, the display will show the following message:

```
Repeat new PIN
Duplicated PIN!
```

This message indicates that the PIN already exists on the system, therefore, the Control panel will consider the Code to be “Disclosed” and, for security reasons, will automatically restore the default PIN of the Code concerned.

If a User attempts to access the system using a “Disclosed” PIN, the display will show the following message:

```
17:05 26/08/2002
Disclosed_PIN!
```

“Disclosed” PINs (at default) must be reprogrammed (refer to Table 7).

“Disclosed” PINs will be signalled by:

- the ▲ LED (ON) on the Keypad
 - the Disclosed PIN! message in **View Trouble** mode
 - the Event details in the Logger
TYPE = Disclosed PIN
IDENT. = the Keypad used
TIME = Time and Date of the Event
- The Trouble status will clear when a New PIN (other than the default PIN) is assigned to the Code with “Disclosed” PIN status.

■ Memo

This command will allow you to record and play voice memos. This command must be enabled on Installer Menu-Program Panel-Configuration-Keypad-Memo.

```
USER MENU
Memo
```

Press **ENTER**:


```
Memo
Record message
```

This option must be duly programmed by the Installer, (Message n.63 only- Quality and Length must be programmed on Installer Menu-Program Panel-Voice Messages) otherwise it will not be available on the Keypad.

To record voice memos

1. Press **ENTER** to start recording.

```
Memo
Remaining9Sec.030
```

The numbers on the second line of the display will indicate the remaining seconds before the end of message. The Green  LED on the Keypad will turn ON to indicate that there is a new memo.


To play voice memos


1. Press **A** or **B** to display **Play message**:

```
Memo
Play message
```

2. Press **ENTER** to play the voice memo:

```
Memo
Remaining9Sec.030
```

The numbers on the second line of the display will indicate the remaining seconds before the end of message. The Green  LED on the Keypad will turn OFF to indicate that there are no unplayed memos.

 *You cannot record a new message until the current message has been played.*

■ **Disable buzzer**


If the Keypad buzzer is Enabled, it will signal the **Entry** and **Exit Times**, and **Violation on Chime zones**. This command will allow you to Disable these audible signals.

When you select this command the display will show the following message:

```
Disable buzzer
Buzzer OFF
```

Press OFF to Disable the buzzer.
Press **1** to Enable the buzzer with low volume.
Press **2** to Enable the buzzer with high volume.

Press the **ENTER** key to step back to the User menu.

 *This command will not Disable the audible feedback signal sounded by the keys .*

■ **Test Siren**

This command will allow you to Test the proper working order of the Alarm signalling devices. If you select this command the Control panel will activate the devices, and the display will show the following message:

```
Test Siren
done!
```

■ **Test Keypad**





This command will allow you to Test the proper working order of the display, LEDs and Keypad. If you select this command the display will show the following message:

```
USER MENU
Test keypad
```

1. Press **ENTER**:

```
ABCDEFGHIJKLMNPO
ABCDEFGHIJKLMNPO
```

If the display is working properly, it will show letters A to P on both lines.

If the , ,  and  indicator LEDs are working properly, they will blink for several seconds.


If the buzzer is working properly, it will sound three times.

■ **Continuous recording**

This command will allow you to record sounds picked up by the system microphones, during and after Alarm and generic events.

To playback sound recording:

1. Use **A** or **B** to scroll for the **Cont. rec. ack** option.

 *This command cannot be selected until one of the Events, programmed by the Installer, occurs.*

```
Continuous rec.
Cont.rec.ack
```

2. Press **ENTER** to start the sound recording playback

```
Continuous rec.
Remaining9Sec.030
```

The second line of the display will show the elapsing time-out. When the remaining seconds go to zero the Continuous Recording elapses.

To reset this command:

1. Use **A** or **B** to scroll for **Cont.rec. reset**:

```
Continuous rec.
Cont.rec. reset
```

2. Press **ENTER** to reset the Continuous Recording facility, and step back to the User menu.

■ **Enable/Disable Timers**

This Control panel manages up to 64 Timers for control of the ON/OFF Times of electrical appliances (Heating systems, Garden sprinklers, Courtesy lights, etc.), and Enabled Times of the system objects (Outputs, Codes, Keys, Cards, etc.). Ask your Installer for details. The **En/Dis Timer** option will allow you to Enable/Disable the Timers, as follows:

1. Use **A** or **B** to scroll for the **Timer** concerned.

```
Timer      001
Timer ON
```

2. Press **ON** to Enable, or **OFF** to Disable the Timer.
3. Press **ENTER** to confirm and go back to the User menu.


■ Enable/Disable Key

The **En/Dis Key** option will allow you to Enable/Disable the Keys, as follows:

1. Use **A** or **B** to scroll for the **Key** concerned, or enter its ID Number.

```
Key        001
Key ON
```

2. Press **ON** to Enable, or **OFF** to Disable the Key.
3. Press **ENTER** to confirm and go back to the User menu.


 **NOTE:** A Key can be Enabled/Disabled **ONLY** by Codes which operate the Partitions it is assigned to.


USING DIGITAL KEYS AND CARDS

The Digital Keys/Cards will allow you to perform all the basic operations from enabled Readers.

Readers

Readers have 3 System status LEDs (Red, Green and Amber).

 Readers can also be used to signal three specific events. Ask your Installer for details.

 If the Compatibility with EN50131 option has been enabled for a reader, after every activation/deactivation the 3 indicator lights will be switched off to “hide” the control unit status.

This Control panel manages:

- **ECLIPSE Readers** (see Figure 3b) - These devices accept commands from SAT Keys (Key must be inserted into the key slot on the Reader).
- **PROXI Proximity Readers** (see Figure 3d) - These devices accept commands from Digital Keys and PROXI-CARDS (the Card/Key must be held near the **sensitive field** of the Reader).
- **PREMIUM LCD Keypads** (see Fig. 3e) - These Keypads have built in **Proximity Readers** Readers and accept com-

mands from Digital Keys and PROXI-CARDS (the Card/Key must be held near the **sensitive field** of the Reader).

KYO 320 manages up to 32 Readers. This Control panel supports up to 32 Readers. The Installer will program the following parameters for each Reader:

- The Partitions the Reader can control (Reader Partitions)
- A Mode Arming (AMBER)
- B Mode Arming (GREEN)

Digital Keys/Cards

This Control panel can manage:

- **SAT Keys** (see Figure 3a) - These work with **ECLIPSE** and **PROXI** Readers.
- **PROXI-CARDS** (see Figure 3c) - These work with **PROXI** Readers only.

The section describes how to operate your system from a Key/Card Reader. Each Key/Card has a random code — selected from over 4 billion combinations.

Your Installer can assign an Identifier Number and Description to up to 500 Keys/Cards. The number will be recorded in the Event Logger each time the Key/Card




Figure 3 a) SAT Digital key, b) ECLIPSE key reader, c) PROXI-CARD, d) PROXI reader, e) PREMIUM LCD keypad.

operates on the System. The Digital Keys/Cards can be programmed to operate on specific Partitions.

In this Manual, the word Reader refers to ECLIPSE and PROXI Readers.

The Reader LEDs

The ECLIPSE Key and PROXI Card Readers simplify system control by replacing User Code PINs with high Security Digital Keys or Cards. The Readers have 3 LEDs, this section describes how the LEDs will signal the System status.

If the reader has been set to Compatibility with EN50131, all the indicator lights will be switched off at the end of the Exit time and Entry time periods.

■ No Key/Card at Reader

When no Digital Key/Card is present at the Reader, the LEDs will signal as shown in Table 6.

The Partitions that are not controlled by the Reader will not affect the LEDs. If the configuration of the Armed Partitions does not match either A or B Mode Arming (for example, one of the Reader Partitions has been Armed via Keypad), neither the Amber nor Green LED will turn ON.

The Installer can program the Reader LEDs to signal the System status at all times, or alternatively, only in response to a Valid Key/Card (LEDs OFF when no Key/Card is present).

■ Key/Card at Reader

When a Key/Card is present at the Reader, the LEDs will signal as follows.

a) Fast Blinking on 1 LED - Before Arming the Partitions, the Control panel will check the status of the Unbypassed (ON) and Instant Zones. If a Zone is 'Violated' (e.g. door or window open), the LED, associated with the selected Arming Mode, will blink quickly. If this occurs, DO NOT ARM the System, as Arming will trigger a False Alarm.

It takes the Control panel about 2 seconds to check all the Zones.

False Alarms can be stopped by simply Disarming the system (refer to "Digital Key/Card Reader operations" in this section). If you accidentally trigger an Alarm, call the Central Station to prevent the operator from taking unnecessary action.

*If, when you Arm the system, the Control panel detects **Autobypassable** zones in Alarm status, it will bypass them automatically. In this way, false Alarms will not be triggered, however, Bypassed zones will be UnBypassed automatically when their Partitions are next disarmed.*

b) Fast Blinking on all 3 LEDs - This will occur when a False Key/Card is present at the Reader.

c) Slow Blinking on all 3 LEDs (ECLIPSE Readers only) - This Mode will allow you to restore the previous setting (reset the Arming Mode that was active before the SAT Key was inserted. To Reset: push the SAT Key into the ECLIPSE Reader until the 3 LEDs start to blink slowly, the previous setting will be restored when you remove the Key.

d) Red LED ON - The System will Arm when you remove the Key/Card from the Reader.

e) Amber LED ON - The System will Arm in A Mode when you remove the Key/Card from the Reader.

f) Green LED ON - The System will Arm in B Mode when you remove the Key/Card from the Reader.

Your Installer may have Disabled the Reader LEDs, therefore, they will not turn ON even when a valid Key/Card is used.

Multiple Systems

The Digital Keys/Cards can be programmed (by the Installer) to operate on more than one System, and to manage different Partitions on each System.

TABLE 6 - LED Status with no Key/Card at Reader

LED	Status	Meaning
RED	OFF	All of the Reader Partitions are Disarmed
	ON	At least one of the Reader Partitions is Armed
	Slow Blinking	At least one Alarm or Tamper event has been detected on one of the Reader Partitions and ALL the Reader Partitions are Disarmed
	Fast Blinking	At least one Alarm or Tamper event has been detected on one of the Reader Partitions and AT LEAST ONE of the Reader Partitions is Armed
YELLOW	ON	The Reader Partitions are Armed in A Mode
	OFF	The Armed/Disarmed status of the Reader Partitions does not match A Mode
GREEN	ON	The Reader Partitions are Armed in B Mode
	OFF	The Armed/Disarmed status of the Reader Partitions does not match B Mode

Digital Key/Card operations

The Digital Keys/Cards can:

- **Arm — Global Mode**
- **Disarm**
- **Arm — A Mode**
- **Arm — B Mode**
- **Stop Alarms**
- **Arm/Disarm Patrol**

☞ *Your Installer may have programmed some “restricted” Digital Keys/Cards. These Keys/Cards will be allowed to perform a maximum number of operations (from 1 to 254) after which, they will be Disabled automatically. Disabled “restricted” Digital Keys/Cards can be re-enabled and refreshed with the same number of operations via the User Menu (refer to Enable/Disable Key/Card).*

■ Disarm (Turning OFF your system)

This operation will Disarm all the Partitions common to both the Digital Key/Card and Reader in use.

To Disarm the System (all LEDs OFF):

1. Insert the SAT Key into the ECLIPSE Reader, or hold the proximity Key/Card near the sensitive field of the PROXI Reader — until all the LEDs turn OFF (see Figure 4a).

☞ *If the Compatibility with EN50131 option has been set for a reader, when a SAT key or valid card is placed near the reader, **the GREEN indicator light will flash briefly and the system will be DEACTIVATED.***

2. Remove the Key/Card to Disarm the System.

■ Arm — Global Mode (Turning ON your system)

This operation will Arm all the Partitions common to both the Digital Key/Card and Reader in use.

To Arm the System in **Global Mode** (Red LED ON):

1. Insert the SAT Key into the ECLIPSE Reader, or hold the proximity Key/Card near the sensitive field of the PROXI Reader — until the Red LED turns ON (see Figure 4b).

2. Remove the Key/Card to Arm the System in Global Mode.

☞ *If the Compatibility with EN50131 option has been enabled for a reader, after the Exit time all 3 indicator lights will be switched off to “hide” the control unit status.*

■ Arm — A Mode

This operation will Arm or Disarm the Partitions in accordance with the **A Mode** Arming configuration (programmed by the Installer).

To Arm the System in **A Mode** (Amber LED ON):

From ECLIPSE Readers

1a. From Disarmed status (Red LED OFF): insert the SAT Key into the ECLIPSE Reader — the Red LED will turn ON (see Figure 4b).

2a. Push the Key once against the switch inside the Reader. The Red LED will turn OFF and the Amber LED will turn ON (see Figure 4c).

3a. Remove the Key. As you remove the Key the Red LED will turn ON and the System will Arm in **A Mode**.

From PROXI Readers

1b. Hold the Proximity Key/Card near the sensitive field of the PROXI Reader. The LEDs will light in turn (at 2 second intervals).

2b. Remove the Key/Card when the Amber LED turns ON. At this point, the Red LED will also turn ON and the System will Arm in **A Mode**.

■ Arm — B Mode

This operation will Arm or Disarm the Partitions in accordance with the **B Mode** Arming configuration (programmed by the Installer).

To Arm the System in **B Mode** (Green LED ON):

From ECLIPSE readers

1a. From Disarmed status (Red LED OFF): insert the SAT Key into the ECLIPSE Reader — the Red LED will turn ON (see Figure 4b).




Figure 4 Disarm/Arm/Stop Alarms from ECLIPSE reader.

2a. Push the Key twice against the switch inside the Reader. The Green LED will turn ON (see Figure 4d).

3a. Remove the Key. As you remove the Key the Red LED will also turn ON and the System will Arm in **B Mode**.

From PROXI Readers

1b. Hold the Proximity Key/Card near the sensitive field of the PROXI Reader. The LEDs will light in turn (at 2 second intervals).

2b. Remove the Key/Card when the Green LED turns ON. At this point, the Red LED will also turn ON and the System will Arm in **B Mode**.

■ Stop Alarms (for ECLIPSE Readers ONLY)

To Stop Alarms: insert a SAT Key into an ECLIPSE Reader (see Figure 4e).

The outcome of this operation depends on how the Installer has programmed the SAT Key.

If the SAT Key has been duly programmed, this operation can:

Stop Partition Alarms generated by Partitions common to the SAT Key and ECLIPSE Reader in use, and/or

Stop Control panel Alarms and/or

Clear the Call Queue (end the ongoing call, and inhibit further Alarm calls).

When the SAT Key is inserted into the Reader, the Red LED will switch status, and the Amber and Green LEDs will turn OFF.

☞ *To restore the setting (reset the Arm Mode that was active before the SAT Key was inserted) — push the SAT Key into the ECLIPSE Reader until the 3 LEDs start to blink slowly, the previous setting will be restored when the Key is removed.*

■ Arm/Disarm Patrol


Digital Keys/Cards with this attribute can Arm/Disarm the system during the programmed Patrol Time.

The Wireless Key


If your system is equipped with a Vector/RX Wireless Receiver, it will be possible to control all the main functions from remote locations by means of Wireless Keys (see Figure 5). This section describes the functions that can be controlled by Wireless Keys.

☞ *The operations performed by Wireless Keys will not be confirmed by any type of feed back signal (audible or visual), unless done in the vicinity of a Reader or a Keypad, or a device that has been especially set up to provide feed back signals.*


■ Global Mode

Press the  button until the LED turns ON (see Fig. 5), to **Arm all the Partitions** of the Wireless Key (KeyFob) in use.


■ Stay Mode

Press the  button until the LED turns ON (see Fig. 5), to **Arm all the Partitions** of the Wireless Key (KeyFob) in use in Stay Mode (A Type- Amber arming) .


■ Disarm


Press the  button until the LED turns ON (see Fig. 5), to **Disarm all the Partitions** of the Wireless Key (KeyFob) in use.

■ Other functions

Press the  key until the LED turns ON (see Fig. 5), to activate the special functions programmed for the Wireless Key (KeyFob) in use (example: B Type- Green arming or Superkey or both).

■ Low Battery

If any of the Wireless Key batteries starts to run low, the  LED on the Keypads will Turn ON.

☞ *All the system Trouble conditions are signalled by the  LED. Therefore, if this LED turns ON, you must access the **View Trouble Mode** for details.*

The Low Wireless Battery condition will be signalled in **View Trouble Mode** by the [Low_battery_WLS] message (refer to “View Trouble Mode” under “Basic Commands” in the “OPERATING YOUR SYSTEM FROM A KEYPAD” section).

The Event Logger (refer to the **IDENT** field of the event **TYPE** [Battery_low_...]) will provide the details of the Wireless key that has triggered the Low battery condition (refer to “Event Logger” under “Accessing the User menu” in the “OPERATING YOUR SYSTEM FROM A KEYPAD” section).

Call your installer and have the battery replaced.




Figure 5 Wireless key

OPERATING THE SYSTEM FROM A TELEPHONE



If your system has a **K3-VOX2** Voice board (accessory item), and your Installer has duly enabled the User Codes, you will be able to control your system via any touch-phone. KYO 320 manages up to 64 Telephone Access User Codes. Each Code can be programmed to control specific functions and Partitions.

You can access the system over the phone:

- after receiving a call from the Control panel;
- after calling the Control panel and activating the Answering device facility.


Remote Access via 'Dialler' mode

If your installer has duly set up your Control panel, the Dialler will send voice messages to the programmed telephone numbers when Alarm conditions are detected (this Control panel manages up to 32 Telephone Numbers). If you receive a Dialler call, you will be able to access your system during the call by entering your **Access Code** on the telephone keypad. You can enter your **Access Code** while the message is playing, or during the pauses between message announcements.

 If the **Confirm successful calls** option is Enabled, you must press the  key (Star) while the voice message is still running, otherwise the Control panel will consider the call "Unsuccessful", and will carry out the programmed Actions.

Remote Access via 'Answer' mode

If your installer has duly set up your Control panels to answer incoming calls, you will be able to access your system via the 'Answering device' facility.

 The Answering function must be Enabled, otherwise, you will be unable to access your system via remote telephone. **DO NOT** use a telephone with a redial button to Arm or Disarm your system, as this may put your system security at risk.

If you are accessing your system via the 'Answering device' facility, two conditions are possible:

- Teleservice Enabled
- Teleservice Disabled.

■ Teleservice Enabled

If the 'Answer' and 'Teleservice' facility are both Enabled, your system will answer your call after the programmed number of rings. It will emit a high-pitch

audible signal (beep), wait approximately 4 seconds then will play the Answer message. At this point, you can enter your PIN and send the required commands over the phone.



■ Teleservice Disabled

If the 'Teleservice' facility is Disabled, your system will answer your call after the programmed number of rings. It will emit a low-pitch audible signal then will play the Answer message. At this point, you can enter your PIN and send the required commands over the phone.

Typing-in your User Code PIN

You can type-in your PIN while the message is playing, or during the pauses between message announcements, regardless of the Telephone Access mode (Dialler or Answer Mode).


To type-in your PIN:

1. Press the  key (for the control panel revision 2.03 or higher),
2. enter your PIN,
3. press the  key.

If your system recognizes your code, it will emit an audible feed back signal (short high-pitched beep), and will accept commands.

If your system DOES NOT recognize your code, it will emit an audible error signal (buzz).


The system will end the call automatically, if no valid code is entered within 30 seconds (at default). This interval can be customized from 1 to 254 seconds.

If necessary, press  to delete wrong digits and restart.


Entering Commands


Once your PIN has been recognized, you can enter the Command Codes. If you enter a wrong Code, the system will emit an audible error signal (buzz).

If you enter a valid Code, the system will emit an audible confirmation signal (beep).


 The system will end the call automatically, if no Key is pressed within 2 minutes.


Cancel Command

Press  to cancel the Command, and step back to the Enter data phase.


Press  to delete wrong digits: the system will emit an audible feed back signal (2 beeps) to confirm that the data has been deleted.


Stop Alarm / On Hook



If you are accessing your system via 'Answering device' mode, press  to end the call.


If you are accessing your system via 'Dialler' mode (after receiving an Alarm message), press  to interrupt the ongoing Alarm, and clear the call queue.

Remote Talk / Listen-in (With K3/VOX2 only).

■ Press  to start the Remote **Listen-in** session, via the system microphones (if installed).



■ Press  again to start the **One-way Talk** session, via the system speakers (if installed).



 If required, press  to switch from **One-way Talk** to **Listen-in** mode, and vice versa. The **One-way Talk** and **Listen-in** modes cannot be active at the same time.

■ Press  to start the **Two-way Talk/ Listen-in** session, via the system microphones and speakers (if installed).

This feature will allow you to listen in on the protected premises and talk to whoever is present.



Two-way Talk/ Listen-in sessions can also be activated by Panic Pendants thus making this feature extremely useful in Emergency situations involving the elderly or disabled.

 If you press  during the **Two-way Talk** session, the Control panel will switch to **Listen-in** mode.



 If the sound quality of the **Two-way Talk** session is poor, use the **One-way Talk** and **Listen-in** modes (press ).

Zone status / Arm Partitions

This command will allow you to check on the Standby/Alarm status of the Zone, and the Armed/Disarmed status of the Partitions.

 The zone or Partition Identifier number **must always be entered with 3 digits** (if necessary enter a  before the number).

1. Press  to access the Zone status/Arm Partitions phase.

2. Press  to access Zone status, or press  to access the Partition status.

Zone status (from step 2)

3a. Enter the Identifier number of the required zone.

If the zone is associated with a voice message, the zone status will be indicated by the message.

If the zone is not associated with a voice message, its status will be signalled by:

1 beep = zone in standby

2 beeps = zone in Alarm or Tamper status.

After the status message or audible signal, the system will go back to step 1.

Arm/Disarm Partitions (from step 2)

3b. Enter the Identifier number of the required Partition.

The current status of the Partition status will be indicated by:



1 beep = Partition Disarmed

2 beeps = Partition Armed

After the audible signal, the system will go back to step 1.

Turn Reserved Outputs ON/OFF

This command will allow you to control (turn ON/OFF) the appliances (Sprinkler system, Courtesy lights, etc.) connected to the **Reserved** Outputs.

 The Output Identifier number **must always be entered with 3 digits** (if necessary enter a  before the number).

1. Press  to access **Output control**.


2. Press  to turn ON, or  to turn OFF the appliance connected to the Reserved Output.


3. Enter the Identifier number of the relevant Output. The appliance will turn ON/OFF immediately, and the system will go back to step 1.





Structured Arming

This command will allow you to Arm or Disarm the system in different modes, in accordance with programming.

1. Press  to access **Structured Arming**.



2. Press  to **Arm** all the entered User Code Partitions in **Away** Mode).

3. Press  to **Disarm** all the entered User Code Partitions.

4. Press either , ,  or  to Arm all the entered User Code Partitions in **A**, **B**, **C** or **D** Mode respectively. The Partitions will Arm/Disarm immediately, and the system will go back to step 1.

Arm/Disarm Single Partitions

This command will allow you to Arm/Disarm the Partitions individually.

 The Partition Identifier number **must always be entered with 2 digits** (if necessary enter a  before the number).

1. Press **5** to access **Arm/Disarm Single Partitions**.
2. Press **1** to Arm, or **0** to Disarm the Partition.
3. Enter the Identifier number of the Partition.

The Partition will turn Arm/Disarm immediately, and the system will go back to step 1.

6 Enable/Disable Teleservice

This command will allow you to Enable/Disable the Teleservice facility

This is a toggle command:

- if Teleservice is **ENABLED**, it will be **DISABLED**: the executed command will be confirmed by an audible feed back signal (low-pitched sound);
- if Teleservice is **DISABLED**, it will be **ENABLED**: the executed command will be confirmed by an audible feed back signal (high-pitched sound).

7 Record/Play Memo (With K3/VOX2 only)

This command will allow you to Record/Play a memo:

- Press **4** to access the Record/Play Memo phase:
- Press **1** to record the message.
- Press **0** to play message.

The end of recording/playback will be signalled by an audible feed back signal (buzz). If you enter a wrong Code, or a message has already been recorded but not played back, the system will emit an audible feedback signal.

8 Reset Alarms


This command will allow you to clear Partition and/or Control panel Alarms restore the system to standby, depending on the Access level of the Code used via Telephone.

9 Enable/Disable Current User Code (ACTIVE)

This command will allow you to select/deselect the **ACTIVE** attribute for the entered User Code.

This is a toggle command:

- if the entered User Code is already **ACTIVE**, it will become **NOT ACTIVE** (Disabled): the executed command will be confirmed by an audible feed back signal (low-pitched sound);
- if the entered User Code is **NOT ACTIVE** (Disabled), it will become **ACTIVE** (Enabled): the executed command will be confirmed by an audible feed back signal (high-pitched sound).

 This security feature will allow you to protect your system against unauthorized access. If you Disable a User Code via Telephone it cannot be used again until it is Re-enabled via the User menu (refer to "Programming PIN Codes" under "Accessing the User Menu").

Default PINs (Factory default)

Table 7, on the following page, shows the default PINs of the User Codes for KYO 320:

- the **No.** column shows the ID number of the User Code;
- the **Description.** column (to be filled in by the Installer) is for the Code User's name;
- the **PIN.** column shows the default PIN of the corresponding User Code. The default PIN will be restored if the secret

Code PIN is duplicated (**Disclosed**) at random (refer to "Programming PIN Codes" in the "OPERATING YOUR SYSTEM FROM A KEYPAD" section).

TABLE 7 - DEFAULT PINS

no.	Description	PIN	no.	Description	PIN	no.	Description	PIN
001		0001	066		0066	131		0131
002		0002	067		0067	132		0132
003		0003	068		0068	133		0133
004		0004	069		0069	134		0134
005		0005	070		0070	135		0135
006		0006	071		0071	136		0136
007		0007	072		0072	137		0137
008		0008	073		0073	138		0138
009		0009	074		0074	139		0139
010		0010	075		0075	140		0140
011		0011	076		0076	141		0141
012		0012	077		0077	142		0142
013		0013	078		0078	143		0143
014		0014	079		0079	144		0144
015		0015	080		0080	145		0145
016		0016	081		0081	146		0146
017		0017	082		0082	147		0147
018		0018	083		0083	148		0148
019		0019	084		0084	149		0149
020		0020	085		0085	150		0150
021		0021	086		0086	151		0151
022		0022	087		0087	152		0152
023		0023	088		0088	153		0153
024		0024	089		0089	154		0154
025		0025	090		0090	155		0155
026		0026	091		0091	156		0156
027		0027	092		0092	157		0157
028		0028	093		0093	158		0158
029		0029	094		0094	159		0159
030		0030	095		0095	160		0160
031		0031	096		0096	161		0161
032		0032	097		0097	162		0162
033		0033	098		0098	163		0163
034		0034	099		0099	164		0164
035		0035	100		0100	165		0165
036		0036	101		0101	166		0166
037		0037	102		0102	167		0167
038		0038	103		0103	168		0168
039		0039	104		0104	169		0169
040		0040	105		0105	170		0170
041		0041	106		0106	171		0171
042		0042	107		0107	172		0172
043		0043	108		0108	173		0173
044		0044	109		0109	174		0174
045		0045	110		0110	175		0175
046		0046	111		0111	176		0176
047		0047	112		0112	177		0177
048		0048	113		0113	178		0178
049		0049	114		0114	179		0179
050		0050	115		0115	180		0180
051		0051	116		0116	181		0181
052		0052	117		0117	182		0182
053		0053	118		0118	183		0183
054		0054	119		0119	184		0184
055		0055	120		0120	185		0185
056		0056	121		0121	186		0186
057		0057	122		0122	187		0187
058		0058	123		0123	188		0188
059		0059	124		0124	189		0189
060		0060	125		0125	190		0190
061		0061	126		0126	191		0191
062		0062	127		0127	192		0192
063		0063	128		0128	193		0193
064		0064	129		0129	194		0194
065		0065	130		0130	195		0195



BENTEL SECURITY s.r.l.

Via Gabbiano, 22

Zona Ind. S. Scolastica

64013 Corropoli (TE) -ITALY

Tel.: +39 0861 839060

Fax: +39 0861 839065

e-mail: infobentelsecurity@tycoint.com

<http://www.bentelsecurity.com>