



INSTRUCTION MANUAL **AUTOMATIC HAIR CURLER**

English - Norwegian

ELLE

EN AUTOMATIC HAIR CURLER

IMPORTANT SAFETY CAUTIONS

The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury, or fire. Arovo cannot be held responsible for any injury or property damage cause by failure to comply with the safety cautions and regulations. It is important to read all these instructions carefully before using the product, and to save them for future reference or new users.

EXPLANATION SYMBOLS

	Read operators manual.
	Do not use over or near washbasins, bathtubs, showers or other vessels containing water.
	Declaration of Conformity. Products marked with this symbol comply with all the applicable Community regulations of the European Economic Area.
	Protection class II device in which protection against electric shock is not based solely on the basic insulation but in which there are additional safety features such as double or enhanced insulation. It is independent of the protection measures of the fixed installation.
	The packaging can be reused or recycled. Please dispose properly of any packaging material no longer required.
	If you notice any transport damage when unpacking the product, please contact your dealer without delay.

WARNINGS

- **WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the risks involved. Children shall not play with the appliance. Cleaning and use maintenance shall not be done by children without supervision.
- Do not keep or use the appliance in humid areas.
- Keep out of reach of children.
- Do not use the appliance with wet hands or let water drop on the appliance. It may cause electric shock and injury. Do not operate the electrical appliance with wet hands or if the appliance is wet.
- Do not place in or drop water or other liquids onto the appliance. If the appliance falls into water, unplug immediately. Do not reach into water.
- Do not operate the appliance in the presence of explosive and/or flammable fumes and/or liquids.
- Do not attempt to repair or disassemble the appliance. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons, in order to avoid any risks.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped into water.
- Do not use an extension cord to operate the appliance. Plug the appliance directly in the electrical outlet.
- Do not bend the electrical cord.
- Keep cord away from the heated surfaces.
- Keep heated surfaces away from contact with all skin areas. Do not let eyes or bare skin touch heated surfaces.

- Do not place the heated unit directly on any surface while it is hot or still plugged in.
- Read operators manual.
- Do not use over or near washbasins, bathtubs, showers or other vessels containing water.
- Declaration of Conformity. Products marked with this symbol comply with all the applicable Community regulations of the European Economic Area.
- Protection class II device in which protection against electric shock is not based solely on the basic insulation but in which there are additional safety features such as double or enhanced insulation. It is independent of the protection measures of the fixed installation.
- The packaging can be reused or recycled. Please dispose properly of any packaging material no longer required.
- If you notice any transport damage when unpacking the product, please contact your dealer without delay.
- Always unplug the appliance immediately after use. Unplug from outlet when the appliance is not in use.
- Never leave the appliance unattended when plugged in. Never use while drowsy or sleepy.
- Do not store the appliance immediately after use. Wait until it is completely cool before storing.
- For additional protection, we advise you to install a residual current device (RCD) with a rated residual operating current not exceeding 30mA in the electrical circuit supplying the bathroom. Ask your installer for advice.
- Do not use the appliance for purposes other than styling human hair.
- Keep the appliance away from non-heat-resistance surfaces and never cover the appliance with anything (e.g. clothing or towels) when it's hot.
- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk even when the appliance is switched off.

TECHNICAL DATA

- 100V-240V~50/60Hz 37W
- PTC heating elements
- Ceramic coating barrel
- Left/right button for turning left or right
- LED Temperature control: 140°C - 230°C
- ON/OFF switch
- Power on indicator light
- 360 degree swivel power cord
- Cable length: 1.8m

GENERAL FEATURES

Please read these instructions carefully before using this product and keep them in a safe place for future reference.

1. Heated barrel with Ceramic coating
2. On/ Off button
3. Power Cord
4. LED display
5. Left button: lock
6. Right button: automatic curl



IN THE BOX

The packaging should contain:

- Automatic hair curler
- User guide: Read these instructions before use

USE

What to do before first use:

- Remove the packaging material and inspect the device for damage.
- Do not operate the device if it is damaged in any way. Return it to your seller immediately.
- Only connect the appliance to a mains socket with the mains voltage indicated on the rating plate.

- When disconnecting the power cord from the power outlet, pull only on the plug. Never pull on the cord.
- During the first few minutes of the first use, you may notice a little smoke and a slight smell. This is normal and will soon disappear.
- Be aware that some surfaces may become hot. Do not touch and supervise others accordingly. The unit is VERY HOT when in use. Take care to avoid contact between the hot surface and bare skin, particularly around the ears, face and neck when in use

INTENDED USE

Warning! Only use the device externally.

- The appliance is only intended for drying and styling human hair.
- Any improper use can be dangerous!
- Preparing the hair: Wash your hair and dry it well. Comb your hair thoroughly. Do not use hairspray or other flammable chemical hair care products.
- Curling Method:
 1. Press the power ON/OFF and waiting for 2 minutes. The temperature will be as selected (with a difference of approx. $\pm 10^{\circ}\text{C}$)
 2. Take about 2 cm wide hair section, start at the bottom of your hair with the tips. Place the hair tips in the curler and press the right triangle button for automatic curling for a few seconds. Hold in place for 5 more seconds. Release the curler and move it down the length of the hair section.
 3. For the first time curling it is better to take less hair to make sure the hair is curled.
- When you are finishing styling, switch off the appliance, unplug the appliance and allow it to completely cool down before cleaning or storing.

CLEANING

Unplug the appliance and allow it to cool down. Use a soft, slightly damp cloth to wipe the appliance surfaces. Do not allow water or any other liquid to get into the unit. Care should be taken not to touch this part of the appliance when it is switched on our just after it has been turned off. ALLOW AT LEAST 30 MINUTES TO COOL DOWN BEFORE PUTTING AWAY.

STORAGE

Unplug the appliance, allow to cool and store in its box or in a dry place. Never store it while it is hot or still plugged in. Never wrap the cord tightly around the appliance. Never hang the unit by the cord. Store the cord loosely coiled. Do not put any stress on the cord where it enters the unit, as it could cause the cord to fray and break

ENVIRONMENT FRIENDLY DISPOSAL



This marking indicates that this product should not be disposed of with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

WARRANTY:

The manufacturer provides warranty in accordance with the legislation of the customer's own country of residence, with a minimum of 24 months, starting from the date on which the appliance is sold to the end user.

- The warranty only covers defects in material or workmanship.
 - The repairs under warranty may only be carried out by an authorized service center. When making a claim under the warranty, the original bill of purchase (with purchase date) must be submitted.
 - The warranty will not apply in cases of:
 1. Normal wear and tear
 2. Incorrect use, e.g., overloading of the appliance, use of non-approved accessories
 3. Use of force, damage caused by external influences
 4. Damage caused by non-observance of the user manual, e.g., connection to an unsuitable main supply or non-compliance with the installation instructions
 5. Partially or completely dismantled appliances
 6. The accessories are not covered by the terms of the warranty because they are subject to wear.
- If you need more information or support, please contact us via: www.arovo.com/contact.

In accordance with our policy of continual product improvement, we reserve the right to make technical and visual changes without notice. The current version of this instruction manual can be found under www.arovo.com/manuals

CE DECLARATION OF CONFORMITY

We, Arovo B.V., Doblijn 26, 1046 BN Amsterdam, The Netherlands declare under our own responsibility that the product:

Article number: **ERP928942430 / 92387**
Article name: **ELLE AUTOMATIC CURLER**
Barcode: **8720297459214**


a) The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:

EMC, LVD, ROHS.

b) Meets the conditions laid down in the following harmonised standards:

EN 60335-2-23:2003+A1:2008+A11 :2010+A11:2010/AC:2012+A2:2015, USED IN CONJUNCTION WITH EN 60335-1 :2012+A11:2014+A13:p2017 and EN 62233:2, IEC 60335-1: 2010 INCL.CORR.1:2010 and CORR.2:2011+A1:2013, IEC 60335-2-23:2003, EN 62233:2008, EN55014- 1:2017, EN55014-2:2015, EN IEC 61000-3-2:2019, EN61000-3-3:2013+A1:2019, (EC)NO 1907/2006, (EU)2015/863 amending Annex II to Directive 2011/65/EU.

The current version of this Declaration of Conformity can be found under www.arovo.com



Michael van Dijk - Quality manager
May 16, 2022
Amsterdam - The Netherlands

AROVO_{bv}
Doblijn 26
1046 BN Amsterdam
The Netherlands
+31 (0) 85 273 88 86

NO AUTOMATISK HÅRKRØLLTANG

VIKTIGE SIKKERHETSINSTRUKSJONER

Følgende sikkerhetstiltak må alltid følges for å redusere risikoen for elektrisk støt, personskade eller brann. Arovo kan ikke holdes ansvarlig for personskader eller materielle skader forårsaket av manglende overholdelse av sikkerhetsreglene og -forskriftene. Det er viktig å lese alle instruksjonene grundig før du bruker produktet og deretter oppbevare dem for fremtidig referanse eller nye brukere.

FORKLARINGER AV SYMBOLER

	Les bruksanvisningen.
	Må ikke brukes over eller i nærheten av servanter, badekar, dusjer eller andre kar som inneholder vann.
	Samsvarserklæring. Produkter merket med dette symbolet er i samsvar med alle gjeldende EU-forskrifter i Det europeiske økonomiske samarbeidsområdet. EU-samsvarserklæringen kan fås ved å skrive til produsenten.
	Beskyttelsesklasse II-apparat der beskyttelse mot elektrisk støt ikke kun er basert på den grunnleggende isolasjonen, men hvor det er ekstra sikkerhetsfunksjoner som dobbelt eller forbedret isolasjon. Den er uavhengig av beskyttelsestiltakene til den faste installasjonen.
	Emballasjen kan gjenbrukes eller resirkuleres. Kast eventuelt emballasjemateriale som ikke lenger er nødvendig.
	Hvis du oppdager transportskader når du pakker ut produktet, må du kontakte forhandleren uten forsinkelser.

WARNINGS

- **ADVARSEL:** Ikke bruk dette apparatet i nærheten av badekar, dusjer, bassenger eller andre kar som inneholder vann.
- Dette apparatet kan brukes av barn som er 8 år og eldre, samt av personer med reduserte fysiske, sensoriske eller mentale evner eller som mangler erfaring og kunnskap, hvis er under tilsyn eller har fått instruksjoner i trygg bruk av apparatet og forstår risikoen som bruken medfører. Barn skal ikke leke med apparatet. Rengjøring og vedlikehold må ikke utføres av barn uten tilsyn.
- Ikke oppbevar eller bruk apparatet i fuktige områder.
- Oppbevares utilgjengelig for barn.
- Bruk ikke apparatet med våte hender eller på et fuktig gulv eller la vann dryppe på apparatet. Det kan forårsake elektrisk støt og personskade. Ikke bruk det elektriske apparatet med våte hender eller hvis apparatet er vått.
- Ikke plasser apparatet i eller søl vann eller andre væsker på apparatet. Hvis apparatet faller i vann, må det kobles fra strømmen umiddelbart. Ikke grip ned i vannet.
- Ikke bruk apparatet i nærvær av eksplosive og/eller brennbare gasser og/eller væsker.
- Prøv ikke å reparere eller demontere apparatet. Hvis strømledningen er skadet, må den skiftes ut av produsenten, dennes servicetekniker eller andre kvalifiserte personer for å unngå evt. risiko.
- Bruk aldri dette apparatet hvis det har skadet ledning eller støpsel, hvis det ikke fungerer som det skal, eller hvis det har falt i vann.
- Ikke bruk en skjøteledning til å bruke apparatet. Koble apparatet direkte til stikkkontakten.
- Ikke bøy den elektriske ledningen.
- Hold ledningen unna oppvarmede flater.
- Hold oppvarmede flater unna kontakt med hudområder. Ikke la øyne eller bar hud berøre varme overflater.

- Ikke plasser den oppvarmede enheten direkte på noen overflate mens den er varm eller fortsatt er tilkoblet.
- Koble alltid apparatet fra strømmen umiddelbart etter bruk. Trekk ut støpselet når apparatet ikke er i bruk.
- Forlat aldri apparatet uten tilsyn når det er koblet til strømnettet. Bruk aldri apparatet når du er døsig eller søvnig.
- Ikke legg bort apparatet til oppbevaring umiddelbart etter bruk. Vent til det er helt avkjølt før du oppbevarer det.
- som ekstra beskyttelse anbefaler vi at du installerer en jordfeilbryter (RCD) med en nominell driftsstrøm som ikke overstiger 30 mA i den elektriske kretsen som forsyner badet. Spør installatøren om råd.
- Ikke bruk apparatet til andre formål enn styling av menneskehår.
- Hold apparatet unna overflater som ikke er varmebestandige, og dekk aldri til apparatet med noe (f.eks. klær eller håndklær) når det er varmt.
- Når apparatet brukes på et bad, må du koble det fra stikkkontakten etter bruk siden nærhet til vann utgjør en risiko selv når apparatet er slått av.

TEKNISKE DATA

- 100V-240V~50/60Hz, 37W
- PTC varmeelement
- Keramisk belagt rør
- Left or right Venstre/høyre knapp
- LED temp. styring 140°C - 230°C
- På/Av-bryter med indikatorlys
- Strømindikatorlampe
- 360 graders svingelstrømledning
- Kabellengde: 1,8m

GENERELLE FUNKSJONER

Les disse instruksjonene grundig før du begynner å bruke dette produktet og oppbevar dem på et sikkert sted for fremtidig referanse.

1. Oppvarmet rør med keramisk belegg
2. På/Av-knapp
3. Strømkabel
4. LED-display
5. Venstre knapp: lås
6. Høyre knapp: automatisk krølltang



I ESKEN

Emballasjen skal inneholde:

- AUTOMATISK HÅRKRØLLTANG
- Bruksanvisning: Les bruksanvisningen før bruk

BRUK

Gjør dette før første gangs bruk:

- Fjern emballasjen og inspisér apparatet for skade.
- Bruk aldri apparatet hvis det er skadet på noen måte. Returner det til selgeren umiddelbart.
- Koble apparatet kun til en stikkontakt med nettspenningen som er angitt på typeskiltet.
- Trekk bare i støpselet når du kobler strømledningen fra strømuttaket. Trekk aldri i ledningen.
- I løpet av de første minuttene ved første gangs bruk kan det oppstå litt røyk og lukt. Dette er normalt og vil snart forsvinne.
- Vær klar over at noen overflater kan bli varme. Ikke berør og instruer andre om dette. Enheten er MEGET VARM når den er i bruk. Sørg for å unngå kontakt mellom den varme overflaten og bar hud når den er i bruk, spesielt rundt ørene, ansiktet og halsen.

BEREGNET BRUK

Advarsel! Bruk enheten kun utvendig.

- Apparatet er kun beregnet til tørking og styling av menneskehår.
- All feil bruk kan være farlig!
- Klargjøring av håret: Vask håret og tørk det godt. Gre håret grundig. Ikke bruk hårspray eller andre brennbare kjemiske hårpleieprodukter.
- Krøllemetode:
 1. Trykk på PÅ/AV og vent i 2 minutter. Temperaturen vil være ca. 140–230 °C (avhengig av valgt temperatur).
 2. Ta en ca. 2 cm bred hårseksjon, start nederst med hårtuppene. Plasser hårtuppene i krølltangen og trykk på høyre trekantknapp for automatisk krølling i noen sekunder. Hold på plass i 5 sekunder til. Slipp krølltangen og flytt den ned langs hårseksjonen.
 3. For første gangs krølling er det bedre å ikke ta så mye hår for å sikre at håret blir krøllet.
- Når du er ferdig med stylingen, slår du av apparatet, kobler det fra strømmen og lar det avkjøles helt før rengjøring eller oppbevaring.

RENGJØRING

Koble fra apparatet og la det avkjøles. Bruk en myk, lett fuktig klut til å tørke av apparatets overflater. Ikke la vann eller annen væske komme inn i apparatet. Sørg for at du ikke berører denne delen av apparatet når det slås på like etter at det har blitt slått av. LA DET AVKJØLES I MINST 30 MINUTTER FØR DU LEGGER DET BORT.

OPPBEVARING

Trek ut støpselet, la apparatet avkjøles og oppbevar det i esken eller på et tørt sted. Oppbevar det aldri mens det er varmt eller fortsatt er tilkoblet. Vikle aldri ledningen tett rundt apparatet. Heng aldri enheten i ledningen. Oppbevar ledningen løst oppkveilet. Ikke belast ledningen der den kommer inn i apparatet, fordi det kan føre til at ledningen slites og går i stykker.

MILJØVENNLIG AVFALLSBEHANDLING



Dette merket angir at dette apparatet ikke må kastes sammen med husholdningsavfall i EU. For å unngå mulig miljøskade eller skade på menneskers helse som skyldes ukontrollert avfallsavhandling, må produktet resirkuleres på en måte som legger til rette for bærekraftig gjenbruk av materialressurser. Buk miljøstasjonene eller returpunktene som er tilgjengelig der du bor, eller kontakt forhandleren der apparatet ble kjøpt. Forhandleren kan ta i mot dette produktet og sørge for miljøvennlig resirkulering.

GARANTI:

Produsenten gir garanti i henhold til lovgivningen i kundens eget bostedsland, med minimum 24 måneder, fra datoen da apparatet ble solgt til sluttbrukeren.

- Garantien dekker kun feil i materialer eller arbeidsutførelse.
- Reparasjonene under garantien kan kun utføres av et autorisert servicesenter. Når du reiser et krav under garantien, må den originale kjøpskvitteringen (med kjøpsdato) sendes inn.
- Garantien gjelder ikke i tilfelle:
 1. Normal slitasje
 2. Feil bruk, for eksempel overbelastning av apparatet, bruk av ikke-godkjent tilbehør
 3. Bruk av makt, skade forårsaket av ytre påvirkninger
 4. Skader forårsaket av manglende overholdelse av bruksanvisningen, for eksempel tilkobling til en uegnet strømforsyning eller manglende overholdelse av installasjonsinstruksjonene
 5. Delvis eller helt demonterte apparater
 6. Tilbehør dekkes ikke av garantien fordi det er utsatt for slitasje.

Hvis du trenger mer informasjon eller støtte, kan du kontakte oss via: www.arovo.com/contact.

I samsvar med vår policy om kontinuerlig produktforbedring forbeholder vi oss retten til å foreta tekniske og visuelle endringer uten varsel.
Den gjeldende versjonen av denne bruksanvisningen finner du på www.arovo.com/manuals

EU-SAMSVARSEKLÆRING

Vi, Arovo B.V., Doblijn 26, 1046 BN Amsterdam, The Netherlands erklærer på eget ansvar at produktet:

Artikkelnummer: **ERP928942430 / 92387**
Artikkelnavn: **ELLE AUTOMATIC CURLER**
Strekkode: **8720297459214**

a) Gjenstanden for erklæringen beskrevet ovenfor er i samsvar med relevant harmoniseringslovgivning i EU:

EMC, LVD, ROHS.

b) Oppfyller vilkårene fastsatt i følgende harmoniserte standarder:

EN 60335-2-23:2003+A1:2008+A11 :2010+A11:2010/AC:2012+A2:2015, USED IN CONJUNCTION WITH EN 60335-1 :2012+A11:2014+A13:p2017 and EN 62233:2, IEC 60335-1: 2010 INCL.CORR.1:2010 and CORR.2:2011+A1:2013, IEC 60335-2-23:2003, EN 62233:2008, EN55014- 1:2017, EN55014-2:2015, EN IEC 61000-3-2:2019, EN61000-3-3:2013+A1:2019, (EC)NO 1907/2006, (EU)2015/863 amending Annex II to Directive 2011/65/EU.

Den gjeldende versjonen av denne samsvarserklæringen finner du på www.arovo.com

van Dijk

Michael van Dijk - Kvalitets ansvarlig
16 Mai 2022
Amsterdam - Nederland

AROVO_{bv}
Doblijn 26
1046 BN Amsterdam
The Netherlands
+31 (0) 85 273 88 86



ELLE

used by AROVO BV under license from
HACHETTE FILIPACCHI PRESSE, France.

ELLE AUTOMATIC HAIR CURLER

ERP928942430 / 92387

2022-1120

Made in China



PLEASE
RECYCLE

Imported by Europris AS
Dikeveien 57, 1661 Rolvsøy, Norway

Manufactured and designed by Arovo B.V.
Doblijn 26, 1046 BN Amsterdam
The Netherlands, www.arovo.com