



# WeatherGuard™

The WeatherGuard™ is designed in two pieces in order to give you maximum versatility. You can use them together to protect your camera gear in poor weather or you can use the pieces separately. The lens section alone can be used as a sunshade while the camera cover alone provides better visibility of the LCD screen if using a digital camera in bright sunlight.


## Instructions




1. Open up the lens section and lay it out flat with the nylon side facing up.



6. WeatherGuard™ should look like this photo at this point.




2. Attach the camera section to the Velcro® strip on the lens section making sure that it's centered.




7. The next three photos show the three different positions of the camera section.

Position: 1<sup>st</sup> snap



3. Flip WeatherGuard™ over and attach Velcro® strip to the right side of the lens section.




Position: 2<sup>nd</sup> snap




4. Attach WeatherGuard™ around the camera lens by pressing the seams together.



Position: 3<sup>rd</sup> snap



5. On the inside of the camera section, assemble and snap the stays into place according to the photo.



8. The WeatherGuard™ includes three 4" Velcro® strips. Two of these strips can be used to hold down the flaps on the inside of the camera section. We've included an extra strip for your use.

**OP/TECH USA**®

304 Andrea Drive • Belgrade, MT 59714  
www.optechusa.com  
Made in the USA

Please call our Customer Service Department at 800-251-7815 if you have any questions.